



Daikin AC Monitoring Tool User Instructions

Step 1

- > Download the "Daikin AC Monitoring Tool" Ap to your phone
- > Enter Company Name
- > Enter Technician Name
- > Enter Sample Rate = 30 Seconds
- > Leave on Manual Stop
- > Units of Measure = PSI/F
- > Press "Accept All Updates"

Step 2

1:1 Single Head Systems

- > Locate the Correct Cord that fits the S2 Plug on the OD Unit Main PCB Board
- > Plug one end of the cord into the Bluetooth Monitor Module
- > Plug the Other End into Main PCB Board on the OD Unit


Multi Head Systems

- > Locate the Correct Cord that Fits the S2 Connector on the Service Monitor Board Next to the Electrical Connections
- > Plug one end of the cord into the Bluetooth Monitor Module
- > Plug the Other End into Service Monitor Board on the OD Unit

Step 3

- > Go to the Bluetooth Settings on your Phone
- > Highlight BTSC
- > Enter 3131
- > Press Pair
- > A Solid Red Light on the Monitor Module Indicates you are Connected

Step 4

- > Return to the Ap and Press the Red Circle
- > Press BTSC = Record Only Button
- > Press the Green Check Mark
- > Next Screen Add New
- > Press the Link Button 
- > Press Unselected Tab
- > From Sub Menu: Choose Single or Multi Split
- > Press the Green Check Mark
- > Choose from the Top Header Boxes for Desired System Data i.e.

Basic Data	Control	Sensor	Actuator	Indoor Unit
------------	---------	--------	----------	-------------